

ITEM	PART#	QTY.	DESCRIPTION
1	5024-1	2	Outer Plate
2	5024-2	2	Inner Plate
3	HDW2051	8	5/16 x 1 Hex Bolt
4	HDW2069	4	5/16 Carriage Bolts
5	HDW7058	12	5/16 Nylock Nut
6	HDW9002	4	5/16 Flat Washer
7	HDW1061	4	8mm x 30mm Hex Bolt
8	HDW9004	4	5/16 Lock Washer

The upper deck will slide together with one inner and one outer plate you will need to figure out the width you need to the bottom holes where it will attach to you machine and then bolt the inner and outer together using 2 – 5/16 x 1 Hex bolts and flat washers on each side then use a nylocks nut on the inside. Secure to you machine with proper hardware.

The Basket will attach to the top of the Upper Deck using the 4 – 5/16 x 3/4 Carriage Bolt going down through the basket and use the remaining 5/16 nylock nuts to secure on the bottom.

(NOTE: Mounting to Polaris or Can-Am you will need to purchase there bed locks)

(NOTE: the metric bolt are for attaching to the CF-Moto 1000 on the top of the box)

