

WINCH MOUNT INSTRUCTIONS
02-08 YAMAHA GRIZZLY 660

ITEM	QTY.	PART#	DESCRIPTION
1	1	1546-1	Main Winch Plate
2	2	HDW2050	5/16 x 3/4 Hex Bolt
3	2	HDW9002	5/16 Flat Washer
4	2	HDW1054	8mm x 25mm Hex Bolt
5	2	HDW7058	5/16 Nylock Nut

Temporarily remove the top bolts that hold the front plastic guard in place.

Install the winch mount behind the front bumper and on the inside of the frame tabs and align the holes in the winch mount plate with the holes in the end of the frame tubes. Install the 5/16 x 3/4 hex bolts and washers down through the winch mount then the frame tabs and install with the 5/16 nylock nuts. Now install the 8mm x 25mm hex bolts through the lower bumper tube then through the winch mount plate and into the frame tube ends.

Install the winch to plate with hardware provided with winch. The cable should come off the top of the spool to relieve stress on the cable

Install fairlead with hardware provided with winch and wire to there instruction.

