

WINCH MOUNT INSTALLATION INSTRUCTIONS  
KAWASAKI 650i BRUTE FORCE 2010-2012  
KAWASAKI 750 BRUTE FORCE 2005-2017

ITEM	QTY.	PART#	DESCRIPTION
1	1	1548-1	Winch Mount Plate
2	4	HDW2150	5/16 x 1-1/8 x 1-3/4 Rd. U-Bolt
3	8	HDW7058	5/16 Nylock Nut
4	8	HDW9002	5/16 Flat Washer

**NOTE:** Fairlead is not included with the winch kit

Remove the upper plastic bumper cover.

Remove the two bolts on the lower plastic bumper cover for easier access.

Attach the winch mount to the frame tubes as shown using the U-bolts, washers and nylock nuts provided. Have the winch so the cable is coming of the bottom of the spool or drum.

Attach the fairlead and winch with hardware provided by winch manufacturer and wire to there instructions.

