

WINCH MOUNT INSTALLATION INSTRUCTIONS  
2004-2013 YAMAHA RHINO 450, 660, 700

ITEM	QTY.	PART#	DESCRIPTION
1	1	1552-70	Winch Mount Plate
2	4	HDW2051	5/16 x 1 Hex Bolt
3	4	HDW7058	5/16 Nylock Nut
4	8	HDW9002	5/16 Flat Washer

**NOTE:** Fairlead is not included with this winch mount kit

- 1 – Remove the front skid plate
- 2 – Install winch mount plate onto bumper as shown in the illustration with the 4 5/16 x 1 hex bolts, washer top and Bottom and nylock nuts.
- 3 – Winch should be installed so cable is coming of the bottom of the spool or drum.
- 4 – Attach fairlead to mount with hardware provided with winch and wire to there instructions.

