

WINCH MOUNT INSTRUCTIONS  
01-04 Honda 500 Rubicon

ITEM	QTY.	PART#	DESCRIPTION
1	1	1559-1	Winch Mount Plate
2	4	HDW9407	7/8" U-Clamp
3	4	HDW2004	1/4 x 1-3/4 Hex Bolt
4	4	HDW7050	1/4 Nylock Nut

1. Remove the front plastic bumper guard.
2. Position the winch mount behind the front bumper and align with the arms of the bumper per illustration.
3. Install the 4 u-clamps from the inside out on the bumper arms as shown and then install the winch mount to the underside on the u-clamps on the bumper arms and use the 1/4 x 1-3/4 hex bolts and nuts to secure.
4. Install winch to mount using hardware provided with winch. Cable should come out between winch and winch mount. NOTE: Winch will hang upside down.
5. Install fairlead with hardware provided with winch.
6. Using the instructions provided with the winch, wire accordingly.

7. Before reattaching the plastic front bumper guard, trim the opening where the roller fairlead goes through. The opening is between the (4) mounting bolts of the guard. Trim straight down from the bottom edge of the opening 3-1/2" or to the top of the skid plate behind the guard and then straight across from side cut to side cut, removing this piece.

8. Reinstall the plastic front bumper guard and bolts. Tighten all bolts evenly.

**NOTE: Roller fairlead not included with this kit!**

