

ITEM	QTY.	PART#	DESCRIPTION
1	1	1567-1	Winch Mount Plate
2	1	1567-2	Fairlead Bracket
3	4	HDW2050	5/16 x 3/4 Hex Bolt
4	4	HDW7058	5/16 Nylock Nut
5	2	HDW9003	5/16 Flat Washer
6	2	HDW1051	8mm x 20mm Flange Head Bolt

## WINCH MOUNT INSTALLATION INSTRUCTIONS

YAMAHA

03-06 4000/450 Kodiak - 04-06 350 Bruin

07-08 400/450 Grizzly – 07-13 350 Grizzly

**NOTE:** Fairlead is not included with this mount kit

- 1 – Temporarily remove the top two skid plate bolts and then remove the front bumper.
- 2 – Install the fairlead bracket to the winch mount with the 5/16 x 3/4 bolts and nylock nuts.
- 3 – Install the winch mount on to the bumper to the forward tabs using the 5/16 x 3/4 bolts, washers and nylock nuts  
Washers will go on bottom side.
- 4 – Install winch to winch mount plate using hardware provided with winch. If winch is on back of plate make sure cable is coming of the top of the drum.
- 5 – Re-install the bumper onto ATV lining the back tabs of the winch mount up with the upper bumper legs and use the 8mm x 20mm flange bolts on the middle bumper leg location. Re-attach the skid plate also.
- 6 – Attach fairlead to fairlead bracket with hardware provided with winch and wire to their instructions.

