

YAMAHA WOLVERINE WINCH MOUNT
INSTRUCTIONS
95-05 YFM 350 WOLVERINE
PART# 4505-0665

NOTE: Fairlead is not included with this kit

ITEM	PART#	QTY.	DESCRIPTION
1	1589-1	1	Winch Mount Plate
2	1589-5	2	Side Mount Plate
3	1589-200	2	Offset Bracket
4	1589-100	1	Oil Cooler Bracket
5	HDW1054	2	8mm x 25mm Hex Bolt
6	HDW2100	4	3/8 x 1 Hex Bolt
7	HDW7061	4	3/8 Nylock Nut

Unplug the headlights and remove the oil cooler from bumper (keep bolts). Remove the bumper and keep bolts. Remove oil lines from the cooler for relocation. Install winch to winch mount with hardware provided with winch. Cable should come off the bottom of spool. Install winch mount to the frame at the bumper mounting locations. Use the bumper bolts you remove to re-install mount. Bolt should go through side mount plate then the winch mount and into the bumper mounting tabs on frame. In the top location you will also have the oil cooler mounting on the outside. Once in place reinstall the oil lines on opposite side from original, the lines will cross each other. Install bumper to mount plate using the 3/8 x 1 hex bolts and nylock nuts provided in kit. Install the small offset brackets between the top bumper mounts and the frame tabs using the original bolts and the 8mm x 25mm hex bolts provided in kit. Hook up the headlights. Install the fairlead with bolts provided with winch and wire to there instructions.

