

WINCH MOUNT INSTRUCTIONS
 11-13 John Deere Gator 825i
 2013 John Deere Gator 855D

ITEM	QTY.	PART#	DESCRIPTION
1	1	1622-1	Winch Mount Plate
2	4	HDW9419	1 x .38 Spacer
3	4	HDW2061	5/16 x 1-1/4 Hex Bolt
4	4	HDW7056	5/16 Flange Nut
5	4	HDW9002	5/16 Flat Washer

NOTE: Fairlead is not included with this kit.

1. Remove front brushguard
2. Place the 4 spacer (2) over the holes in the frame as illustrated bellow.
3. Orientate the winch so the cable is coming off the bottom of the spool. Bolt the winch on to the mount plate With hardware provided with winch.
4. Once winch is installed place mount in place on top of the spacers and make sure the holes are aligned. With the holes aligned drop the bolts with washers on down through the winch mount plate and spacers. Use the flange nut to secure from the bottom side. **NOTE:** Place the flange nut inside a box end wrench and reach in the frame channel to get them started. Attach the fairlead to the mount with hardware provided with winch
6. Follow the winch manufacturer's instructions and wire the winch.
7. Reinsall the front brushguard.

