

**WINCH MOUNT INSTRUCTIONS  
HONDA TALON**

ITEM	PART#	QTY.	DESCRIPTION
1	1641-1	1	Winch Mount Plate
2	HDW9205	4	5/16 x 1-1/2 x 2-3/16 Rd. U-Bolt
3	HDW2079	2	5/16 x 1-1/2 x 2-3/16 Sq. U-Bolt
4	HDW7058	12	5/16 Nylock Nut
5	HDW9002	12	5/16 Flat Washer

Remove the side bolts on that hold plastic to bumper.

Remove the front bumper.

Place winch mount in place as shown in picture and use the 4 - 5/16 round U-bolts, washers and nuts to attach to frame tubes. Leave Loose for now.

Slide bumper back in place. Depending on winch you may have to slide winch in place before installing the front bumper back on.

Once bumper is installed back in place you can Attach the front portion of the mount with the 2 - 5/16 square U-bolts, washers and nuts then align winch mount and tighten securely.

Attach winch with hardware provided with winch and wire to there instructions.

**NOTE:** Winch will hang upside down so cable should come of the top and through fairlead.

Re-attach the plastic to bumper when all completed.

