ITEM	PART#	QTY.	DESCRIPTION
1	1645-1	1	WINCH MOUNT PLATE
2	HDW1050	2	8mm x 20mm HEX BOLT

Place the winch mount inside the bumper and on top of the front bumper cross support plate.

Use the 2-8mm hex bolt in the back of the mount to secure to the pre-threaded holes in the frame. Do not completely tighten at this time.

The front part of mount will secure with the winch bolts when you place winch in. NOTE: if using larger winch you will need to use the mount as a guide and drill these hole in place.

Mount fairlead with bolts provided with winch and wire to winch manufactures instructions.

