



POLARIS EXPEDITION WINDOW CLOSURE  
PART# 4049

ITEM	PART#	QTY.	DESCRIPTION
1	3049-1	1	Right Window
2	3049-2	1	Left Window
3	HDW1050-BLK	8	M8 x 20MM Hex Bolt
4	HDW1041-BLK	4	M8 Nylock Nut
5	HDW9002-BLK	8	5/16 Flat Washer

Window closure will go on the inside.

Use 2 of the Hex bolts, Washers and Nylock Nuts on the top corners as shown in top picture.



The bottom portion will use 2 hex bolts and washers.

You will have to remove bolts that are in place on the rail system and replace with the one in the kit.

Align and tighten.

