



ITEM	PART#	QTY.	DESCRIPTION
1	5590-70	1	Receiver Weldment
2	5590-4	1	Rear Flange
3	HDW9477	4	3/8 x 3-1/2 Carriage Bolt
4	HDW9478	4	3/8 x 5 Carriage Bolt
5	HDW9001	4	3/8 Flat Washer
6	HDW7061	4	3/8 Nylock Nut

You can align this adaptor to most frame tubes and attach it using the rear flange on the back side.

Choose your length of bolt that would best fit your application and bolt up the 2" receiver tube. Make sure bolts are as close to the frame tube as can be and tighten securely.

