Receiver Hitch HONDA 2007-14 Rancher 420 (Straight Axle Models) 2005-14 Foreman/Rubicon 500

Part Number: 1183

Item	Qty.	Part#	Description
1	1	1183-70	Receiver Hitch 10mm Low Profile Nut
2	2	HDW9190	Tomm Low Profile Nut

Instructions:

- 1. Remove the stock hitch. Remove the nuts from the top two rear axle to differential studs. (See Illustration). **NOTE:** Some models use hex bolts, remove the top two.
- Slide the receiver hitch in place over the factory ball hitch location. Be sure to align the bracket onto the studs (or bolts) on the rear axle. Bolt the receiver hitch in place using the original hardware. NOTE: Put the bolts in from the bottom of the hitch with the nuts on top.
- 3. Install the included low profile nuts onto the studs (on applicable models) holding the rear bracket. NOTE: You must use some Blue Loctite on the threads to keep the nuts from coming loose. Tighten firmly. NOTE: Some differentials will have nuts to use and some will have bolts that thread in, either way use some Loctite to keep secure.



QUESTIONS OR COMMENTS PLEASE CALL: **320-964-1616** Monday thru Thursday 7:00 to 4:30 CST