



ITEM	PART#	QTY.	DESCRIPTION
1	6016	1	Base Plate
2	HDW1120-BLK	8	M6-1.0 Nylock Nut
3	HDW1086-BLK	2	M6-1.0 x 20mm Hex Bolt
4	HDW9012-BLK	8	1/4" Flat Washer
5	6019-2	4	Fender Washer
6	6019-3	2	Backing Plate
7	HDW7050	6	1/4" Nylock Nut
8	6019-4	6	1/4"-20 x 3/4 Milled Carriage Bolt
9	6019-5	4	1/8 x 5-1/4" Long Adhesive Gasket
10	HDW9505	2	BRP Linq Base Assembly

### BRP LINQ ADAPTOR PLATE FOR POLARIS SNOWMOBILES



Attach the BRP LINQ ASSEMBLIES to the base plate in the needed places using the mounting hardware that came with the LINQ BASE ASSEMBLY.

Depending on your accessory you may use just one set of the BRP LINQ brackets in either one of the three position.

On the Polaris snowmobiles you will use the 1/4" milled carriage bolts to slide into the tunnel rails. On older models you will align base plate up in desired position and use the base plate as a template to drill through tunnel and then use the M6 x 230mm bolt washers and nylock nut to bolt down through the tunnel. Make sure you are clearing the cooler plates.

Place the Base Plate on to the bolts as shown and tighten down using the 1/4" whiz nuts.

You should be able to use most BRP LINQ product with the adaptor plate.



## BRP LINQ ADAPTOR PLATE FOR ARCTIC CAT



Shown on CATALYST chassis for older Arctic Cats you will have to line up the mount plate where you desire to place it and drill through for all 8 mounting holes. Make sure you are clearing the cooler plate.

Depending on the BRP accessory you may use just one of the BRP LINQ brackets in either one of the three positions.

Attach the BRP LINQ ASSEMBLIES to the Base Plate using the hardware that came with the BRP LINQ BASE.

Remove the Arctic Cat accessory mount brackets and use these holes to first mount the base plate to with the black M6 x 20mm bolts going down through the plate and tunnel. Use the backing plate and nylock nuts to secure going on the underside of the tunnel.

There are other holes and hardware to use to secure the base plate down with. You will use the base plate as a template and drill through the tunnel and when bolting down use the bolt washer and nylock nut with the washer going on the underside with the nut.

You should be able to use most BRP LINQ product with this plate.