

HERC



Outdoors

HERC Link Connector for Can-Am

ITEM	PART#	QTY.	DESCRIPTION
1	6027-1	2	Lower Clamp with Stud
2	6027-2	2	Spacer Member
3	HDW9119-1	2	Female Knob
5	HDW9015	2	Rubber Sealing Washer

Follow these steps to securely install your **Herc Links** on your UTV:

1. **Remove the Knob** – Unscrew and remove the knob from the top of the bolt.
2. **Position the Herc Link** – Place the Herc Link in your desired location on the UTV.
3. **Lock the Metal Plate** – Rotate the bolt and pull up to ensure the metal plate at the bottom locks into place.
4. **Secure the Rubber Washer** – While still pulling up on the bolt, slide the rubber washer all the way down until it sits flush against the spacer.
5. **Attach Your Accessory** – Position your accessory on top of the bolt.
6. **Tighten the Knob** – Twist the knob back on until it is fully tightened and secure.

