

ITEM	PART#	QTY.	DESCRIPTION
1	5505-70	1	Hitch Main Weldment
2	5505-4-70	1	Nut Plate
3	HDW9105	1	1/2 x 2 Hex Bolt
4	HDW7089	1	1/2 Nylock Nut
5	HDW2051	2	5/16 x 1 Hex Bolt
6	HDW9004	2	5/16 Lock Washer

Remove the two bolts on the lower bumper support.

Place the hitch on machine as shown with by sliding the channel of the hitch into the receiver hitch on machine and the tab on the back of the hitch will go under the bumper support bracket where you removed the two bolts from.

The bottom portion will mount up with the 1/2 x 2 bolt going through the receiver hitch on machine and the hitch your installing, use the 1/2" nylock nut to secure.

On the back portion use the 2 – 5/16" x 1" bolt with lock washer to go down through bumper bracket and thread into the nut plate which will slide under the frame bracket with the nuts facing downward.

Once it is all in place tighten.

