

# Receiver Hitch Installation Instructions

KAWASAKI

'05-'14 610 Mule

Part Number: 1269

Qty.	Part#	Description
1	1269-1	Hitch
2	HDW1041	8mm Nylock Nuts
2	HDW1055	8mm x 35mm Hex Bolts
2	HDW2401	5/16" x 2" x 2-1/2 Square U-Bolts
4	HDW7058	5/16" Nylock Nuts
4	HDW9002	5/16" Flat Washers

## INSTRUCTIONS:

1. Remove the 15mm OEM bolts and washers and discard.

**NOTE:** Before proceeding, match up the 5/16" hardware and 8mm hardware by threading the nuts on the bolts by hand. Failure to do so could result in cross-threaded hardware.

2. Install the (2) square U-Bolts around the frame per the illustration using the 5/16" washers and nuts. Do not tighten.
3. Install the (2) 8mm x 35mm bolts and 8mm nuts provided per the illustration.
4. Tighten all nuts and bolts.

