




ITEM	PART#	QTY.	DESCRIPTION
1	5301	1	Rear Rack
2	HDW9387	2	M8 x 50mm Button Head Screw
3	HDW9386	2	M8 x 40mm Button Head Screw
4	HDW9488	2	3/4" x 5/8" Spacer
5	HDW9489	2	5/8" x 1" Spacer

YAMAHA TENERE 700 REAR RACK



First remove the 4 side posts just below the back portion of the seat.


Place the aluminum spacer in these locations with the longer ones going in the forward position and shorter ones in the back position.

Place the rack on top and use the 50mm button heads in the forward position and the 40mm button heads in the back position.

Make sure the spacers are going into the hole in the plastic for proper fit and tightening.

Rack is not intended to be used as a seat and the recommended weight is 40 pounds. Do not use rack as a lifting device or grab rail.

The rack does have a roto-pax bolt up location in the middle if desired.



QUESTIONS OR COMMENTS CALL: 320-964-1616, Monday thru Thursday 7:00 to 4:30 CST