



ITEM	PART#	QTY.	DESCRIPTION
1	6020HO	1	BRP Rack Adaptor Mount
2	6021HO	1	Cross Bar Tube
3	5526HO	1	1-1/4" Receiver Mount
4	5016HO	1	Tent Holder

Attach Rack adaptor to snowmobile with quick lock Kit for your machine.

Use one cross bar up front for stability and the second cross tube in desired position on where you want the tent holder to go.

Attach the 1-1/4 Receiver Mount to the cross bar tube with U-Bolts provided.

Assemble the tent holder and slide into the receiver mount and pin in place.

Tent holder can go sideways or length wise.

