

ITEM	QTY.	PART#	DESCRIPTION
1	1	1547-1	Main Winch Plate
2	2	HDW2050	5/16 x 3/4 Hex Bolt
3	2	HDW7058	5/16 Nylock Nut
4	2	HDW9002	5/16 Flat Washer
5	2	HDW9009	7/16 Split Lock Washer
6	2	HDW1066	10mm x 20mm Hex Bolt

NOTE: Fairlead is not included with this kit.

WINCH MOUNT INSTRUCTIONS
07-15 YAMAHA GRIZZLY 700 / 09-14 GRIZZLY 550

Position the winch mount (1) in the front of machine as shown in illustration.

Use the 10mm x 20mm hex bolts (6) and 7/16 flat washers (5) in the upper back of the mount going into the tabs with the threads in them.

Use the 5/16 x 3/4 hex bolts (2) and washers (4) to go into the hole toward the front of the mount and into the tabs and secure with the 5/16 nylock nuts (3).

Attach winch and fairlead with hardware provided by the winch manufacturer and wire per there directions.

