

FENCE STRETCHER PART# 5038HO

Take all parts out of box.

First you will slide the Main Hitch Member and slide it into the hitch. The end with the 7 holes will slide into the hitch.

Now attach the Spool Holder Rack to the Main Hitch Member top portion at the height preference. NOTE there is a second set of holes in case you want to add another Spool Holder Rack to run two lines. Attach per picture using the 2 – 5/8 x 3-1/4 bolts and Nylock nuts.

Now attach the right and left incline plates. The form on the plate will face outward, attach with the 3/8 x 2-1/4 bolts and nylock nuts. NOTE: on the far back bolt there is a flat washer on the outside with the nut.

You will need to attach the slotted stop gate 1 on each side using the 3/8 x 1/2 shoulder bolt 3/8 flat washer and the 5/16 nylock nut. Do not tighten all the way this need to be able to move.

ITEM	PART#	QTY.	DESCRIPTION
1	5038-70	1	Main Hitch Member
2	5038-65	1	Spool Holder Rack
3	5038-60	1	Axel
4	5038-1	1	Left Incline Plate
5	5038-2	1	Right Incline Plate
6	5038-9	1	Roller Washer
7	5038-3	2	Slotted Stop Gate
8	HDW9132	2	5/8 x 3-1/4 Hex Bolt
9	HDW9438	2	5/8 Nylock Nut
10	HDW9121	4	3/8 x 2-1/4 Carriage Bolt
11	HDW7061	4	3/8 Nylock Nut
12	HDW9001	4	3/8 Flat Washer
13	HDW7058	2	5/16 Nylock Nut
14	HDW9448	2	3/8 x 1/2 Shoulder Bolt
15	HDW9065	2	1-1/2 Square Tube Plug



FENCE STRETCHER PART# 5038HO

Once the fence stretcher is assembled you can slide the Axle through a roll of wire and place the Roll Washer on.

Flip open the Slotted stop gates place axle with wire into the incline plates and then flip and lock down the slotted stop gates.

USE with caution.



Questions or comments call 320-964-1616 Monday thru Thursday 8:00 to 4:30 CST

INST5038HO