


**5627H
BIG BUDDY HOT DIGGITY DOG COOKER**



Simply place the Hot Diggity Dog Cooker in the vent slots on top and place it in the center.

Place you dogs or brats in the groves and rotate until evenly cooked.

Do not let grease drip on to burner. Do not leave unattended and watch for fires.

Clean you cooker plate frequently.



QUESTION OR COMMENTS CALL: 320-964-1616, Monday thru Thursday 7:00 to 4:30 CST